


## YOUR NEW 3WAY COMBINATION UNIT

### Remote Control (TV Function Buttons)

You can use the remote control up to about 23 feet from the TV.  
When using the remote, always point it directly at the TV.

- 1 POWER**  
Turns the 3way Combination Unit on and off.
- 2 +100**  
Press to select channels over 100. For example, to select channel 121, press "+100," then press "2" and "1."
- 3 MTS (Multichannel Television Stereo)**  
Press to choose stereo, mono or Separate Audio Program (SAP broadcast).
- 4 MUTE**  
Press to temporarily cut off the sound.
- 5 VOL +, VOL -**  
Press increase or decrease the volume.
- 6 S.MODE**  
Adjust the TV sound by selecting one of the preset factory settings (or select your personal, customized sound settings).
- 7 MENU**  
Displays the main on-screen menu.
- 8 Control the cursor in the menu**  
Allows move to items.




- 9 TV/VCR ↔ DVD selection**  
Press to switch between TV/VCR, and DVD mode.
- 10 PRE-CH**  
Tunes to the previous channel.
- 11 INPUT**  
Press to watch the TV picture or a picture from a connected component (VCR, camcorder etc...)
- 12 SLEEP**  
Press to select a preset time interval for automatic shutoff.
- 13 CH ∨ and CH ∧ (Channel Down/Up)**  
Press CH ∨ or CH ∧ to change channels.
- 14 P.MODE**  
Adjust the TV picture by selecting one of the preset factory settings (or select your personal, customized picture settings).
- 15 INFO**  
Press to see the channel, time, current disc mode, audio/video settings etc., on-screen.
- 16 ADD/DEL**  
Press to add or erase channels in the TV's memory.

## YOUR NEW 3WAY COMBINATION UNIT

### Remote Control (DVD Function Buttons)

- 1 Search**  
Press to search forward/backward through a disc.
- 2 Stop**  
Press to stop a disc.
- 3 ENTER**  
Confirms a selection.
- 4 OPEN/CLOSE**  
Press to open or close the disc tray.
- 5 STEP**  
Press to advance play one frame at a time.
- 6 ZOOM**  
Press to zoom-in during playback, slow motion or pause mode on the selected area of a scene.
- 7 ANGLE**  
Press to access various camera angles on a DVD.
- 8 PROGRAM**  
For program play.




- 9 Skip**  
Press to skip the title, chapter, or track.
- 10 Play/pause**  
Press to play or pause disc play.
- 11 DVD MENU**  
Displays the DVD play's Setup menu.
- 12 SUBTITLE**  
Press to display the subtitle language name abbreviation on-screen.
- 13 RETURN**  
Press to return to a previous menu or exit.
- 14 AUDIO**  
Press to access various audio functions on a disc.
- 15 CLEAR**  
Press to clear on-screen displays.
- 16 BOOKMARK**  
Press to memorize scenes for replay.
- 17 REPEAT**  
Press to repeat play a title, chapter, track, or disc.

**YOUR NEW 3WAY COMBINATION UNIT**

**Remote Control (VCR Function Buttons)**




- 1 TRK+, - (tracking)**  
Press to adjust tape tracking.
- 2 REW/F.F**  
Press to rewind/fast forward a video tape.
- 3 Stop**  
Press to stop a video tape.
- 4 OPEN/CLOSE**  
Press to eject a tape.
- 5 F.ADV (frame advance)**  
Press to advance a tape frame-by-frame.
- 6 SP/SLP**  
Press to select the tape recording speed.



- 7 P.PLUS**  
Press to compensate for a poor rental tape.
- 8 SLOW+, -**  
Press to watch a tape in slow motion.
- 9 Play/pause**  
Press to play or pause a tape.
- 10 REC**  
Press to begin recording.

## INSTALLATION

### Installing Batteries in the Remote Control



◀ Make sure to match the "+" and "-" ends of the batteries with the diagram inside the compartment.

◀ Remove the batteries and store them in a cool, dry place if you won't be using the remote control for a long time.

The remote control can be used up to about 23 feet from the TV.

(Assuming typical TV usage, the batteries last for about one year.)