










Remote control buttons

Button	Function
	SETUP. Starts all programming sequences. Remote LED. Blinks when the remote is being programmed or is sending a signal to your LCD TV. POWER. Turns the selected component on and off.
	Programs the remote control to recognize a component. For programming instructions, see "Programming the remote control" on page 7. TV. Selects a programmed TV. Pre-programmed for your 23-inch or 26-inch LCD TV. DVD. Selects a programmed DVD player. Pre-programmed for Gateway's DVD player. VCR. Selects a programmed VCR. TV2. Selects a second programmed TV. Pre-programmed for Gateway's 42-inch or 50-inch plasma TV. CBL/SAT. Selects a programmed cable TV set-top box or selects a programmed satellite TV set-top box. AMP. Selects a programmed amplifier. CD. Selects a programmed CD player. AUX. Selects a programmed component. Pre-programmed for Gateway's Media Center PC.

Button	Function
 	Number button pad. Selects a channel or enters a password. MUTE. Turns the sound on and off. 100. Scans four channels at a time in TV mode. Works as an Enter button in other video modes.
 	VOL. Turns volume up or down. LAST. Recalls the previously viewed channel. SLEEP. Turns on the sleep timer. INPUT. Changes the input source. CH. Changes the channel.

Button	Function
	WIDE/GUIDE. Cycles through standard and widescreen viewing modes or accesses programming guides, such as the one that comes with a satellite dish. GUIDE does not work in TV mode. INFO. Shows the current status of your LCD TV, such as the video input source, audio status, and channel number. △, ▽, ◀, ▶. Navigates the on-screen display (OSD) menus. OK. Works as the Enter button. EXIT. Closes the component, guide, or OSD menus. MENU. Enters the OSD menus.
	◀◀ Reverse. Rewinds the CD, DVD, or VCR when the component is activated with the remote control. ▶ Play. Plays the CD, DVD, or VCR when the component is activated with the remote control. ▶▶ Forward. Forwards the CD, DVD, or VCR when the component is activated with the remote control. ● Record. Records the CD, DVD, or VCR when the component is activated with the remote control. ■ Stop. Stops the CD, DVD, or VCR when the component is activated with the remote control. Pause. Pauses the CD, DVD, or VCR when the component is activated with the remote control.


Button	Function
	FREEZE. Freezes the display image.
	ZOOM. Turns ZOOM mode on and off.
	AUDIO. Selects STEREO, SAP, or MONO when in TV mode.
	PIP. Turns picture-in-picture (PiP) mode on and off.
	PIP mode does not work when parental controls are set.
	YPbPr. Selects the component connected to component video connector as the input source.
	CC. Turns CLOSED CAPTION mode on and off.
	RGB. Selects the component connected to the RGB connector as the input source.
	DVI. Selects the component connected to the DVI connector as the input source.
	TV. Selects TV as the input source.
	AV1. Selects the component connected to the AV1 connector as the input source.
	AV2/S2. Selects the component connected to AV2 connector as the input source.
	AV3. Selects the component connected to the AV3 connection as the input or output source.

Inserting batteries



To install batteries:

- Insert two AA batteries into the remote control. Make sure that you match the + and – on the batteries with the + and – symbols inside the battery compartment.



Programming the remote control

The TV component button has been preset to work with your Gateway LCD TV (program code 0080). You can program the remote control to work with as many as seven other components.



To program the remote to control other components:

- 1 Turn on the component.
- 2 Press the matching component button on the remote control.
- 3 Press and hold the **SETUP** button until the LED flashes twice.
- 4 Enter the programming code for the component and manufacturer. For a list of component programming codes, see "Component program codes" on page 8. If the code is accepted, the LED flashes twice after the last digit is entered.

If the LED does not flash twice, repeat Steps 2 through 4 with the next code listed for the component and manufacturer.

Important



Make sure that you try all the codes listed until you find the one that works for the component.

- 5 Point the remote control at the component and press the **POWER** button. The component should turn off.



Tips & Tricks



If you cannot find your manufacturer in the component list or the program code does not work, you can use the remote control to search for the correct component code. See "Searching for component codes" on page 19.

Component program codes

Use the codes in the following tables to program the remote control to work with your audio and video components.

Amplifier and tuner codes

Manufacturer	Program Code	Manufacturer	Program Code
Bose	0674	Polk Audio	0892
GE	0078	Realistic	0395
Harman/Kardon	0892	Sony	0689
JVC	0331	Soundesign	0078
Marantz	0892	Victor	0331
Optimus	0395	Wards	0078
Philips	0892	Yamaha	0354

Cable set-top box codes

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
ABC	0003, 0017	Philips	0305, 0317
Americast	0899	Pioneer	0144, 0533, 0877
Bell South	0899	Pulsar	0000
General Instrument	0276, 0476, 0810	Quasar	0000
Goldstar	0144	Regal	0273, 0279
Hamlin	0009, 0273	Runco	0000
Jerrold	0003, 0276, 0476, 0810	Samsung	0144
Memorex	0000	Scientific Atlanta	0017, 0477, 0877
Motorola	1106	Starcom	0003
Pace	0237	Toshiba	0000
Panasonic	0107, 0000	Zenith	0000, 0525, 0899
Paragon	0000		

CD player codes

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
Aiwa	0157	Parasound	0420
Burmester	0420	Philips	0157, 0626
California Audio Labs	0029	Pioneer	0032, 0468, 0305, 1062, 1063
Carver	0157, 0179	Polk Audio	0157
DKK	0000	Proton	0157
Denon	0003, 0873	QED	0157
Emerson	0305	Quasar	0029
Fisher	0179	RCA	0053, 0032, 1062, 0468, 0305, 0179
Garrard	0420	Realistic	0179, 0420
Genexxa	0032, 0305	Rotel	0157, 0420
Harman/Kardon	0157, 0173	SAE	0157
Hitachi	0032	Sansui	0157, 0305
JVC	0072	Sanyo	0179
Kenwood	0028, 0190, 0826, 0037, 0626, 0681	Scott	0305
Krell	0157	Sears	0305
LXI	0305	Sharp	0037, 0861
Linn	0157	Sherwood	1067
MCS	0029	Sonic Frontiers	0157
MTC	0420	Sony	0000, 0490
Magnavox	0157, 0305	Soundesign	0145
Marantz	0157, 0626, 0029	Tascam	0420
Mission	0157	Teac	0420
NSM	0157	Technics	0029

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
Onkyo	0101, 0868	Victor	0072
Optimus	0032, 0468, 0420, 0179, 0305, 1063, 0000, 0037, 0145	Wards	0053, 0157
Panasonic	0029	Yamaha	0036, 0888

DVD player codes

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
Apex	0672	Optimus	0571
Denon	0490	Oritron	0651
Fisher	0670	Panasonic	0490, 0677, 0632
Gateway	0081	Philips	0539, 0503
GE	0522	Pioneer	0571, 0525, 0632
Gradiente	0651	Proscan	0522
Hitachi	0573, 0664	RCA	0522, 0571
Hiteker	0672	Samsung	0573
JVC	0623, 0558	Sharp	0630
Kenwood	0682, 0534	Sony	0533
Konka	0719, 0711, 0720, 0721	Technics	0490
Magnavox	0503, 0675	Theta Digital	0571
Marantz	0539	Toshiba	0503
Mitsubishi	0521	Yamaha	0490, 0545
Onkyo	0503	Zenith	0591, 0503

Computer and Home automation codes

Manufacturer	Program Code	Manufacturer	Program Code
Gateway	1272	Security System	0167
GE	0240	Universal X10	0167
One For All	0167	X10	0167
Radio Shack	0240		

Receiver codes

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
ADC	0531	Panasonic	0039, 1518
Aiwa	0121, 1405, 1089	Philips	1089, 1189, 1269
Bose	0238, 0639, 1229, 1253, 1355, 1356, 1357	Pioneer	0150, 0531, 0630, 1023
Capetronic	0531	Proscan	1254
Carver	1089, 1189	Quasar	0039
Denon	1160, 1104	RCA	1254, 0531, 1023
Harman/Kardon	0110	Sansui	1089
JBL	0110	Sharp	0186
JVC	0074	Sony	1158, 1058, 1258
Kenwood	1027, 0186, 1313, 1569, 1570	Soundesign	0670
MCS	0039	Sunfire	1313
Magnavox	1089, 0531, 1189	Technics	0039, 1308, 1518, 1309
Marantz	1189, 1089, 0039	Thorens	1189
Onkyo	0135	Victor	0074
Optimus	1023, 0186, 0531, 0670	Yamaha	0176, 0186, 1176

Satellite set-top box codes

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
AlphaStar	0772	Next Level	0869
Chaparral	0216	Panasonic	0247, 0701
Echostar	0775, 1005	Philips	1076, 1142, 0722, 0724, 0749
Expressvu	0775	Proscan	0392
GE	0566	RCA	0566, 0392, 0143, 0855
General Instrument	0869	Radio Shack	0869
HTS	0775	Samsung	1109
Hitachi	0819	Sony	0639
Hughes Network Systems	0749, 1142, 1749	Star Choice	0869
JVC	0775	Toshiba	0749, 0790
Magnavox	0722, 0724	Uniden	0724, 0722
Memorex	0724	Zenith	0856
Mitsubishi	0749		

TV codes

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
AOC	0019, 0030	Memorex	0179, 0463, 0178, 0016, 0056, 0150, 0154, 0250
Admiral	0093, 0463	Midland	0017, 0047, 0051
Aiko	0092	Mitsubishi	0150, 0178, 0019, 0093
Aiwa	0701	Motorola	0093
Akai	0030	Multitech	0180
Alaron	0179	NAD	0156, 0166, 0178
America Action	0180	NEC	0030, 0019, 0056
Anam	0180	NTC	0092

Programming the remote control

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
Audiovox	0092, 0180, 0451, 0623	Nikko	0178, 0030, 0092
Baysonic	0180	Onwa	0180
Belcor	0019	Optimus	0250, 0166, 0154
Bell & Howell	0016, 0154	Optonica	0093
Bradford	0180	Orion	0463, 0179, 0236
Brockwood	0019	Panasonic	0051, 0250
Broksonic	0236, 0463	Penney	0047, 1347, 0060, 0030, 0178, 0051, 0019, 0056, 0156
CXC	0180	Philco	0145, 0019, 0030, 0054, 0463
Candle	0030, 0056	Philips	0054
Carnivale	0030	Pilot	0019, 0030
Carver	0054	Pioneer	0166, 0679
Celebrity	0000	Portland	0019, 0092
Cineral	0451, 0092	Princeton	0717
Citizen	0056, 0030, 0060, 0092	Prism	0051
Concerto	0056	Proscan	0047
Contec	0180	Proton	0178
Craig	0180	Pulsar	0017, 0019
Crosley	0054	Quasar	0051, 0250
Crown	0180	RCA	0047, 1347, 1147, 0679, 1247, 0019, 0051, 0090, 0093, 1047, 1447
Curtis Mathes	0060, 0030, 0016, 0047, 0051, 0054, 0056, 0093, 0145, 0154, 0166, 0451, 1147, 1347	Radio Shack	0180, 0030, 0178, 0154, 0019, 0047, 0056
Daewoo	0092, 0623, 0019, 0624, 0451	Realistic	0180, 0154, 0030, 0178, 0019, 0056

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
Daytron	0019	Runco	0017, 0030
Denon	0145	SSS	0019, 0180
Dumont	0017, 0019	Sampo	0030
Electroband	0000	Samsung	0060, 0019, 0178, 0030, 0056
Emerson	0236, 0180, 0178, 0179, 0463, 0624, 0623, 0019, 0154	Sansei	0451
Envision	0030	Sansui	0463
Fisher	0154	Sanyo	0154
Fujitsu	0179, 0683	Scimitsu	0019
Funai	0180, 0171, 0179	Scotch	0178
Futuretech	0180	Scott	0236, 0019, 0178, 0179, 0180
Gateway	0072, 0080	Sears	0154, 0056, 0156, 0047, 0054, 0171, 0178, 0179
GE	0047, 1347, 0051, 0178, 0451, 1147, 0093	Semivox	0180
Gibralter	0017, 0019, 0030	Semp	0156
GoldStar	0178, 0019, 0030, 0056	Sharp	0093, 0688
Gradiente	0056, 0053	Shogun	0019
Grunpy	0179, 0180	Signature	0016
Hallmark	0178	Sony	0000
Harley Davidson	0179	Soundesign	0178, 0179, 0180
Harman/Kardon	0054	Squareview	0171
Harvard	0180	Starlite	0180
Hitachi	0145, 0056, 0016	Supreme	0000
Infinity	0054	Sylvania	0054, 0030

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
Inteq	0017	Symphonic	0171, 0180
JBL	0054	TMK	0056, 0178
JCB	0000	TNCi	0017
JVC	0053	Tandy	0093
KEC	0180	Technics	0051, 0250
KTV	0180, 0030	Technol Ace	0179
Kenwood	0030, 0019	Techwood	0051, 0056
Konka	0707, 0632, 0628, 0638, 0703	Teknika	0016, 0054, 0179, 0180, 0019, 0092, 0056, 0060, 0150
LG	0056	Telefunken	0056
LXI	0154, 0047, 0054, 0156, 0178	Toshiba	0156, 0060, 0154, 1256
Logik	0016	Vector Research	0030
Luxman	0056	Victor	0053
MGA	0150, 0019, 0030, 0178	Vidikron	0054
MTC	0060, 0030, 0019, 0056	Vidtech	0019, 0178
Magnavox	0054, 0030, 0179, 1254	Wards	0054, 0178, 0016, 0019, 0030, 0056, 0179
Majestic	0016	White Westinghouse	0624, 0623, 0463
Marantz	0054, 0030	Yamaha	0019, 0030
Matsushita	0250	Zenith	0017, 0624, 0016, 0092, 0463
Megatron	0145, 0178		

VCR codes

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
Admiral	0048, 0209	Mitsubishi	0043, 0048, 0067
Adventura	0000	Motorola	0035, 0048
Aiko	0278	Multitech	0000, 0072
Aiwa	0000, 0037	NEC	0038, 0067, 0104
America Action	0278	Nikko	0037
American High	0035	Noblex	0240
Asha	0240	Olympus	0035
Audiovox	0037	Optimus	0162, 1062, 1162, 0048, 1262, 0037, 1048, 0104, 0432
Beaumark	0240	Orion	0479, 0002, 0184, 0209
Bell & Howell	0104	Panasonic	0035, 0162, 1162, 1262, 1362, 0616, 1062
Broksonic	0121, 0184, 0002, 0209, 0479	Penney	0035, 0240, 0037, 0042, 0038
CCE	0072, 0278	Pentax	0042
Calix	0037	Philco	0035, 0209, 0479
Canon	0035	Philips	0081, 0035, 0618, 1081, 1181
Carver	0081	Pilot	0037
Cineral	0278	Pioneer	0067
Citizen	0278, 0037	Polk Audio	0081
Colt	0072	Profitronic	0240
Craig	0037, 0072, 0047, 0240	Proscan	0060
Curtis Mathes	0035, 0060, 0162	Protec	0072
Cybernex	0240	Pulsar	0039
Daewoo	0278, 0045	Quasar	0035, 0162, 1162

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
Denon	0042	RCA	0060, 0149, 0042, 0035, 0048, 0240
Dynatech	0000	Radio Shack	0000, 1037
Electrohome	0037	Radix	0037
Electrohome	0037	Randex	0037
Emerex	0032	Realistic	0000, 0104, 0047, 0048, 0037, 0035
Emerson	0184, 0002, 0209, 0278, 0121, 0479, 0000, 0037, 0043	ReplayTV	0614, 0616
Fisher	0047, 0104	Runco	0039
Fuji	0033, 0035	STS	0042
Funai	0000	Samsung	0045, 0240
GE	0035, 0060, 0048, 0240	Sanky	0039, 0048
Garrard	0000	Sansui	0479, 0000, 0067, 0209
Go Video	0432	Sanyo	0047, 0104, 0240
GoldStar	0037, 0038	Scott	0184, 0121, 0043, 0045
Gradiente	0000	Sears	0037, 0042, 0000, 0035, 0047, 0104
HI-Q	0047	Semp	0045
Harley Davidson	0000	Sharp	0048
Harman/Kardon	0038, 0081	Shintom	0072
Harwood	0072	Shogun	0240
Hitachi	0042, 0000	Singer	0072
Hughes Network Systems	0042	Sony	0033, 0032, 0000, 0035, 0636, 1032
JVC	0067	Sylvania	0035, 0081, 0000, 0043
KEC	0037, 0278	Symphonic	0000

Manufacturer	Program Code(s)	Manufacturer	Program Code(s)
KLH	0072	TMK	0240
Kenwood	0067, 0038	Teac	0000
Kodak	0035, 0037	Technics	0035, 0162
LXI	0037	Teknika	0000, 0035, 0037
Lloyd's	0000	Thomas	0000
Logik	0072	Tivo	0618, 0636
MEI	0035	Toshiba	0045, 0043
MGA	0043, 0240	Totevision	0037, 0240
MGN Technology	0240	Unitech	0240
MTC	0000, 0240	Vector	0045
Magnasonic	0278	Vector Research	0038
Magnavox	0035, 0081, 0563, 0000, 0039, 0149	Video Concepts	0045
Magnin	0240	Videosonic	0240
Marantz	0081, 0035	Wards	0035, 0060, 0000, 0047, 0240, 0042, 0048, 0072, 0081, 0149
Marta	0037	White Westinghouse	0072, 0278, 0209
Matsushita	0035, 0162	XR-1000	0072, 0000, 0035
Memorex	0104, 0047, 0479, 0000, 0037, 0048, 0035, 0240, 1037, 0039, 0162, 0209, 1162, 1262	Yamaha	0038
Minolta	0042	Zenith	0039, 0000, 0033, 0209, 0479

Searching for component codes

If you cannot find your manufacturer in the component list or the program code does not work, you can use the remote control to search for the correct component code.



To search for a component code:

- 1 Turn on the component.
- 2 Press the matching component button on the remote control.
- 3 Press and hold the **SETUP** button until the LED flashes twice.
- 4 Press **9 9 1**. The LED flashes twice.
- 5 Point the remote control at the component and alternate between pressing the **POWER** button and the component button on the remote control until the component turns off.



If the component still does not respond, clear the component button, then repeat the search procedure.



To clear the component button:

- 1 Make sure that the component is turned on.
- 2 Press and hold the **SETUP** button on the remote control until the LED flashes twice.
- 3 Press **9 9 2**, then press the component button on the remote control twice.



Reassigning component buttons

You can reassign the component buttons on the remote control if you have more than one of the same type of component.

Example:

If you are using the remote to control the cable (CBL), DVD, TV, and two VCRs, you can reassign the CD button as a second VCR button.



To reassign component buttons:

- 1 Press and hold the **SETUP** button until the LED flashes twice.
- 2 Press **9 9 2**. The LED flashes twice.
- 3 Press the component button that you want (**VCR**) once, then press the component button that you are reassigning (**CD**) once. The CD button is now reassigned and can be programmed as a VCR component button. See "Programming the remote control" on page 7.



Changing volume lock

The remote control can be set to control volume through your TV while in cable (CBL), DVD, CD, and VCR component modes. Use the volume lock if you want to control the volume for all components through a specific component.

Example:

You want to control volume for all components through the receiver (AUX).



To change the volume lock:

- 1 Press and hold the **SETUP** button until the LED flashes twice.
- 2 Press **9 9 3**. The LED flashes twice.
- 3 Press the component button that you want (**AUX**) once. The LED flashes twice. Volume will now be controlled through the receiver for all components.



Teaching the remote control new functions

The remote control can learn up to 25 additional functions from the component's original remote control.

Example:

Your DVD player remote control has a scan function that you may use frequently. There is not a scan button on the remote control. You can assign a button and use the DVD remote to teach the remote control the scan function.

Important



Make sure that you have already programmed the remote control for the component. See "Programming the remote control" on page 7.

Make sure that area lighting is not too bright or it will interfere with the learning process.



To teach the remote control a new function:

- 1 Press and hold the **SETUP** button on the remote control until the LED flashes twice.
- 2 Press **9 7 5**. The LED flashes twice.
- 3 Press the component button that you want (**DVD**) once.
- 4 Press the button on the LCD TV remote control that you are assigning the new function to. The LED flashes quickly while it is waiting to receive the signal from the teaching remote control.
- 5 Hold the teaching remote control approximately 1-inch (2.54 cm) from the LCD TV remote control making sure that the infrared ports are lined up, then press the button on the teaching remote control that you want the remote control to learn. The LED flashes twice.
- 6 Press the **SETUP** button to exit learning mode.

