


Remote Control Unit



- 1 POWER (p. 21)
- 2 ▲ OPEN/CLOSE (p. 24)
- 3 AUDIO (p. 30), SUBTITLE (p. 30)
- 4 Number buttons (p. 34)
- 5 REPEAT (pp. 29, 30)
- 6 ⏮ SKIP/◀ (pp. 27, 29)
- 7 ⏭ SKIP/▶ (pp. 27, 29)
- 8 ⏸ PAUSE (p. 29)
- 9 ▶ PLAY (p. 24)
- 10 TOP MENU/TITLE LIST (pp. 25, 27)
- 11 Cursor buttons (▲/▼/◀/▶), ENTER (pp. 22, 35)
- 12 EXIT (pp. 21, 35)
- 13 A (Red), B (Green), C (Blue), D (Yellow) (pp. 27, 32, 41)
- 14 🔒 (Lock) (See below.)
- 15 COMPONENT RESET (p. 36)
- 16 DISPLAY (pp. 24, 30)
- 17 TV CONTROL buttons (p. 22)
- 18 FUNCTION (pp. 31, 33)
- 19 ⏭ FWD (p. 29)
- 20 ⏮ REV (p. 29)
- 21 ■ STOP (p. 24)
- 22 POP-UP MENU (p. 25)
- 23 ↶ RETURN (p. 29)
- 24 HDMI (p. 36)
- 25 SETUP (pp. 22, 35)

Keylock function

You can set the keylock to prevent accidental operations. This function allows TVs compatible with AQUOS LINK to also perform a Key Lock on the player.

Press and hold 🔒 (Lock) for more than 5 seconds.


- Each time you perform this operation, the function is activated or deactivated.
- If you try to operate the Player while the keylock function is set, "Hold" blinks on the front display panel to indicate that the keylock function is set.

Hold


Before Starting Playback

Loading the Batteries in the Remote Control


- 1 Hold in the tab on the battery cover and pull the cover towards the direction of the arrow.



- 2 Load the two "AA" size batteries (R-06 size, UM/SUM-3). Place batteries with their terminals corresponding to the \oplus and \ominus indications in battery compartment.




- 3 Insert the smaller tab of the battery cover into the opening ①, and press down on the cover until it clicks in place ②.



NOTE


- Do not subject the remote control unit to shock, water or excessive humidity.
- The remote control unit may not function if the Player's remote sensor is in direct sunlight or any other strong light.
- Incorrect use of batteries may cause them to leak or burst. Read the battery warnings and use the batteries properly.
- Do not mix old and new batteries, or mix different brands.
- Remove the batteries if you will not use the remote control unit for an extended period of time.

Approximate operating range of remote control



Connecting the Power Cord


Plug the supplied AC cord into the AC IN terminal on the rear of the Player. Then plug into AC outlet.



NOTE

- Place the Player close to the AC outlet, and keep the power plug within reach.
- TO PREVENT RISK OF ELECTRIC SHOCK, DO NOT TOUCH THE UN-INSULATED PARTS OF ANY CABLES WHILE THE AC CORD IS CONNECTED.
- The ON/STANDBY indicator blinks while the Player is preparing for starting up. You cannot turn the Player on until the ON/STANDBY indicator stops blinking.

Language Setting




Changing the on-screen display language


- 1 Press **SETUP** to display the Setup Menu screen.



- 2 Press **▲/▼/◀/▶** to select "On Screen Language", then press **ENTER**.



- 3 Press **▲/▼** to select the language you want to display on the screen, then press **ENTER**.




NOTE

- To select the DVD disc language, such as subtitle language, etc., see page 25.

Operating a SHARP TV Using the Remote Control

The Universal Remote Control may operate the basic functions of the SHARP TV.

TV function control



- TV Power: POWER
- TV-AV Selector: INPUT
- TV Volume up/down: VOL + / -
- TV Channel up/down: CH ▲ / ▼