


## 2 Use your Blu-ray disc/ DVD player

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers (e.g. product software upgrade), visit [www.hd.philips.com](http://www.hd.philips.com).

### Basic play control




During play, press the following buttons to control.

| Button                  | Action                                                                                                                             |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------|
|                         | Access the home menu.                                                                                                              |
|                         | Stop play.<br>Press and hold (more than 4 seconds) to open or close the disc compartment.                                          |
|                         | Pause play.<br>Press repeatedly to slow forward frame by frame.                                                                    |
|                         | Start or resume play.                                                                                                              |
|                         | Skip to the previous or next track, chapter or file.                                                                               |
|                         | Fast backward or forward.<br>Press repeatedly to change the search speed.<br>Press  once, and then press  to slow forward.         |
| AUDIO                   | Select an audio language or channel.                                                                                               |
| SUBTITLE                | Select a subtitle language.                                                                                                        |
| DISC MENU / POP-UP MENU | Access or exit the disc menu.                                                                                                      |
| TOP MENU                | Access the main menu of a video disc.                                                                                              |
| Color buttons           | Select tasks or options for Blu-ray discs.<br>Press <b>Netflix</b> to connect to Netflix.<br>Press <b>Vudu</b> to connect to Vudu. |
|                         | Navigate the menus.<br>Press  to rotate a picture clockwise or counter-clockwise during slideshow.                                 |
| OK                      | Confirm a selection or entry.                                                                                                      |
|                         | Return to a previous display menu.                                                                                                 |
|                         | Access more options during play.                                                                                                   |

## Video, audio and picture options

More options are available for video or picture play from a disc or USB storage device.

### Video options



Access more options during video play.

- **[Audio Language]:** Select an audio language.
- **[Subtitle Language]:** Select a subtitle language.
- **[Subtitle Shift]:** Change the subtitle position on the screen. Press ▲ ▼ to change the subtitle position.
- **[Info]:** Display play information.
- **[Character Set]:** Select a character set that supports the DivX video subtitle (only for DivX videos).
- **[Time Search]:** Skip to a specific time via the numeric buttons on the remote control.
- **[2nd Audio Language]:** Select the second audio language (only for Blu-ray discs that support BonusView).
- **[2nd Subtitle Language]:** Select the second subtitle language (only for Blu-ray discs that support BonusView).
- **[Titles]:** Select a title.
- **[Chapters]:** Select a chapter.
- **[Angle List]:** Select a camera angle.
- **[Menus]:** Display a disc menu.
- **[PIP Selection]:** Display a picture-in-picture window (only for Blu-ray discs that support BonusView).
- **[Zoom]:** Zoom into a video picture. Press ◀▶ to select a zoom factor.
- **[Repeat]:** Repeat a chapter or title.
- **[Repeat A-B]:** Mark two points within a chapter for repeat play, or turn off repeat mode.
- **[Picture Settings]:** Select a predefined color setting.

#### Note

- Available video options depend on the video source.