


















Getting Started

Logos of Discs that can be played

			
Blu-ray Disc	3D Blu-ray Disc	DTS-HD Master Audio	DivX
			
BD-LIVE	Dolby TrueHD	NTSC broadcast system in U.S.A, Canada, Korea, Japan	Java

Accessories

Check for the supplied accessories below.

			
Audio/Video cable (AK39-00148A)	User Manual (AK68-01960U)	Quick Guide (AK68-01855W)	
			
AC power Adapter (AK44-00012A)	Car Power Cable (AK39-00150A)	Battery Pack (AK43-01004A)	Remote Control with CR2032 Type Lithium-Ion Battery (AK59-00104U)
			
Earphones (AK30-00007A)	Y type Earphone Adapter (3722-003034)	Soft Cloth (AH81-02286C or BN63-02368B)	
			Carrying Case (AK63-00709A)

! CAUTION

- Operating the product while in the carrying case may increase internal temperature, which may damage the product. Do not turn on or operate the product while covered in the carrying case.