

3. TV+3 TEXT KEY = SIZE, ENTER KEY = CC, EPG KEY = BRIGHT

HERE IS THE STEP YOU NEED TO FOLLOW AFTER CHANGING THE BATTERY ON THE REMOTE CONTROL.

PLEASE CLICK ON TV+3.