


## BRIEF MODEL MATCHING FOR REMOTE CONTROL SVA-U01

1. TV+1 ◀ KEY = PIP
2. TV+2 HERE IS THE STEP YOU NEED TO FOLLOW AFTER CHANGING THE BATTERY ON THE REMOTE CONTROL, PLEASE CLICK ON TV+2
3. TV+3 TEXT KEY = SIZE, ENTER KEY = CC, EPG KEY = BRIGHT  
HERE IS THE STEP YOU NEED TO FOLLOW AFTER CHANGING THE BATTERY ON THE REMOTE CONTROL, PLEASE CLICK ON TV+3,
4. TV+4 OK KEY = MENU, MENU KEY = PICTURE  
HERE IS THE STEP YOU NEED TO FOLLOW AFTER CHANGING THE BATTERY ON THE REMOTE CONTROL, PLEASE CLICK ON TV+4,
5. TV+5 CH- = - / --, ▼ KEY = CH-, ▲ KEY = CH+, ▲ KEY = VOL-, ▽ KEY = VOL+  
HERE IS THE STEP YOU NEED TO FOLLOW AFTER CHANGING THE BATTERY ON THE REMOTE CONTROL, PLEASE CLICK ON TV+5
6. TV+6 TV/VIDEO KEY = DTV/ TV, PICTURE KEY = SOURCE, V-CHIP KEY = SIZE, SIZE KEY = PIC. MODE, I KEY = PIP, ■ KEY = S.MODE, SOUND KEY = PC/ H DMI, TEXT KEY = S.VIDEO, COMPONENT, ENTER KEY =   
HERE IS THE STEP YOU NEED TO FOLLOW AFTER CHANGING THE BATTERY ON THE REMOTE CONTROL, PLEASE CLICK ON TV+6