

Chapter 9

Apps Collaboration

Using Apps on a Tablet or Smartphone

Toshiba provides three apps for tablets and smartphones:

- ❖ Toshiba A/V Remote App
- ❖ Toshiba Send & Play App
- ❖ Toshiba MediaGuide App

These apps are available for compatible Toshiba equipment using compatible tablets and smartphones powered by Android™ or IOS. You can download these apps through the Google Play™ or the iTunes Store.

In order to use these apps, you must configure the settings through the Apps Control Profile.

- NOTE**
- ❖ Third party Internet services are not provided by Toshiba, may change or be discontinued at any time, and may be subject to Internet service provider restrictions. Toshiba makes no warranties, representations, or assurances about the content, availability, or functionality of third-party content or services. Use of third-party Internet services may require the creation of a separate account through a computer with Internet access and/or payment of one-time and/or recurring charges and membership. Not all third-party services may be available on or compatible with this product. In order to experience the full suggested capabilities of this product, fully-compatible devices may be required.
 - ❖ The Toshiba A/V Remote App can only be used when your TV and your tablet or smartphone are connected to the Internet.
 - ❖ The Toshiba Send & Play App can only be used when your TV and your tablet or smartphone are connected to the Internet.
 - ❖ The Toshiba MediaGuide App can only be used when your TV and your tablet or smartphone are connected to the Internet.
 - ❖ Starting and operation of this service may take several minutes.
 - ❖ Software updates may be needed in order to use this service.
 - ❖ In order to experience the full suggested capabilities of this product, fully-compatible devices may be required.
 - ❖ Certain features may not be available in all countries.
-

Apps Control Profile

To select the Apps Control Profile

- 1 Press the **MENU** button. Select **NETWORK, Network Device Setup** and press the **OK** button.
- 2 Use the (**▲/▼** arrow) buttons to select **Apps Control Profile** and press the **OK** button.

The Apps Control Profile window will appear.

- 3 Use the (**▲/▼** arrow) buttons to select **Device Registration Setup** and press the **OK** button.

The Device Registration Setup window will appear.

- 4 Use the (**▲/▼** arrow) buttons to highlight the **Companion Device ID**.
- 5 Select the **Cancel, All, or Delete** buttons.


To enable the New Device Detection:

- 1 Press the **MENU** button. Select **NETWORK, Network Device Setup** and press the **OK** button to select.
- 2 Use the (◀/▶ arrow) buttons to select **Apps Control Profile** and press the **OK** button.
The Apps Control Profile window will appear.
- 3 Use the (▲/▼ arrow) buttons to select **New Device Detection** and press the **OK** button.
- 4 Use the (◀/▶ arrow) buttons to select **Enable** or **Disable**.
- 5 Press the **OK** button to submit.

Initial setup

In order to use this application, your Android™ and/or IOS-compatible tablets or smartphones and compatible Toshiba equipment must be connected to the wireless LAN in your home. After downloading the Toshiba A/V Remote App, follow these steps:

- 1 Read the disclaimer and select the **Agree** option.
The Toshiba equipment's name will appear in the terminal window of the device powered by Android™.
- 2 Select the desired Toshiba equipment from the list.



(Sample Illustration) Toshiba A/V Remote App—Device Select screen

- 3 Activate the selected device by entering a 4-digit PIN code in the pop-up window on the tablet or smartphone.

- 4 Press the **OK** button on the tablet or smartphone screen.



(Sample Illustration) Toshiba A/V Remote App—Input PIN code screen

Toshiba A/V Remote App

The tablet and smartphone control apps provide multiple pages of options for maximum control. They include the codes needed to operate today's most popular home entertainment electronics.

With this app, you can control your Toshiba TV and other devices connected to it through IP, IR Blaster, or the HDMI CEC functions.

Toshiba Send & Play App

The Toshiba Send & Play App allows you to share a URL from your tablet or your smartphone to your Smart TV.

-
- NOTE**
- ❖ Some web pages or URLs may not launch, depending on the TV status.
 - ❖ Some web pages may not display correctly.
-

Toshiba MediaGuide

The Toshiba MediaGuide App is a channel guide application for tablets and smartphones.

There are four screen modes which display detailed information such as TV Listings, TV Portal, Movies Portal, and Search. The screen modes can be changed using a left or right swipe of the switch bar at the top of the compatible device screen.

TV listings

The TV listings are displayed in a grid format, which is easily controlled by swiping up, down, left, and right with your finger.

Movies/TV portal screen

You can select from the Movie or the TV program Hotlist, their Portals, or the Reminders as desired.

Search screen

You can search by keyword for TV programs, movies, or names of actors for detailed information.

Detailed information

You can browse program and celebrity information, such as celebrities associated with a program, photos associated with a program, airing information for a specific program, programs associated with a celebrity, or photos associated with a celebrity.